



This Part only BlueCab-30

NOTES:UNLESS OTHERWISE SPECIFIED

- 1.ALL RESISTORS (UNLESS POWER AMP BOARD) VALUE ARE IN OHMS 1/8W
- 2.ALL RESISTORS VALUE OF POWER AMP BOARD ARE IN OHMS 1/4W
3. THIS SYMBOL ALERTS YOU TO IMPORTANT OPERATING AND MAINTENANCE INSTRUCTIONS
4. THIS SYMBOL ALERTS YOU TO IMPORTANT OPERATING AND MAINTENANCE INSTRUCTIONS
- 5.CN1=CN1A+CN1B;CN2=CN2A+CN2B;CN3=CN3A+CN3B;CN4=CN4A+CN4B;CN5=CN5A+CN5B

BLUE CAB30(20) SCHEMATIC CIRCUIT DIAGRAM